

Assembling whiteboard cabinets



1. Align cabinets up beside each other and screw together with 1 ¼ screws through the predrilled holes making sure the cabinets are flush at the front. There are holes to screw the cabinets together inside the bottom cavities too. Please be aware you need room to slide the whiteboards in from the left or right of the cabinet into the tracks.
2. Fit the whiteboard tracks with the small screws provided. Track A and B at the bottom as marked and the track C at the top. Do not put screws in the 6 holes at each end of the bottom tracks yet.
Make sure your cabinets are in a straight line. Do not bend the tracks to suit the cabinets but align the cabinets to suit the track so the track stays in a straight line.
3. Slide the whiteboards in one at a time (we recommend putting the board with the handle on the left at the back and the board with the handle at the right at the front). Slide both boards to the centre of the tracks so you have room to work at each end.
4. Fit the track stops into each end of the tracks - these are labelled from 1-4. Once these are installed check to make sure there are screws in every hole in the tracks.
5. Fit the end panels to the left and right hand side of the cabinet using the 1 ¼ screws provided