

# Wall anchor kit instructions (optional)



1. Locate the studs you wish to use to attach the cabinet to the wall.
2. Install these brackets on the inside of the cabinet at the top (see above photo).
3. Using 1 x 8x20mm screw (shorter screw) to attach the bracket to the underside of the top of the cabinet
4. Then use the 2 x 8x50mm screws (longer screws) to attach the bracket to the wall (this will screw through the bracket, then through the white back and then into the wall.)
5. If attaching the cabinet to a concrete / block wall replace the 8x50mm screws with some concrete fasteners